

To Calibrate the Battery and PV Input:

First the solar input must be shut off:

Press **Menu Back** and go to INPUT and Press **Enter**

Press the **Left Arrow** to turn OFF Solar.

Then proceed to calibrate the Battery and PV inputs:

Press **Menu Back** and scroll to the right to TECH and press **Enter**

Select Calibrate and press **Enter**

With a trusted Volt-meter, adjust the displayed Battery voltage to the measured voltage in the voltmeter

Do the same to the Input voltage.

Press the **Save** button to keep the changes

The solar input must be turned back on again:

Press **Menu Back** and go to the INPUT menu, Press **Enter** and turn ON Solar.

Press **Save** again.

Press **Status** to return to the main screen.